

APPLICATION INSTRUCTIONS FOR ANTISLIP

These instructions are a guideline

1. Prepare the tools


- A roller
- A needle
- A cloth
- Alcohol spray / cleaning product
- 3M Primer 94
- A brush



2. Clean the platform surface



3. Apply the Primer (one single layer), wait for at least 10 min.




10-15 min




4. Prepare the antislip




5. Make a 4cm fold, flip it, and place it correctly on the surface




6. *Apply it carefully with your hand following the tucks and lines*



7. Apply firmly, using the roller




8. Pull the sheet smoothly about 10cm with both hands




9. Apply using the roller




10. Repeat the steps 7 + 8 until halfway up



11. At the middle, carefully peel off part of the fold then apply using the roller



12. Repeat until the end of the surface



13. At the end of the surface, break the ankle using a roller




14. Force it on the little surface with your finger




15. Apply using the roller to create adherence



16. Push the sides correctly using the roller, following the all lines of the form



17. Roll strongly on the whole surface



- 18. If you find air bubbles, use the needle and press with your finger, to get the air out**



- 19. You can use the same instructions to apply the antislip on the footrest**



